

Merchant Shipping Notice No.: 23/1996

HONG KONG MERCHANT SHIPPING NOTICE

RECOMMENDATIONS ON THE SAFE USE OF PESTICIDES IN SHIPS

The attached Recommendations on the Safe Use of Pesticides in Ships consolidates amendments and revisions made by the International Maritime Organization up to 1996.

- Masters of Hong Kong registered ships and fumigators in Hong Kong are advised to follow the attached consolidated Recommendations on the Safe Use of Pesticides in Ships when using pesticides in ships.
- Previous recommendations issued under Merchant Shipping Notice No. 21/1993, 28/1993 and 26/1995 are hereby repealed by this Notice.

Marine Department Multi-lateral Policy Division 3 October 1996

RECOMMENDATIONS ON THE SAFE USE OF PESTICIDES IN SHIPS (Revised 1996)

TABLE OF CONTENTS

		Page
Fo	reword	. 3
1	Introduction	4
2	Prevention of infestation	
	2.1 Maintenance and sanitation	5
	2.2 Main sites of infestation	5
3	Chemical control of insect infestation	
	3.1 Methods of chemical disinfestation	6
	3.1.1 Types of pesticides and methods of insect control	6
	3.1.2 Contact insecticides	7
	3.1.3 Fumigants	8
	3.2 Disinfestation of empty cargo spaces	9
	3.3 Disinfestation of food stores, galleys, crew and	
	passenger accommodation	9
	3.4 Disinfestation of cargoes and surrounds	9
	3.4.1 Fumigation of cargo spaces and cargoes	9
	3.4.2 Furnigation with aeration (ventilation) in port	9
	3.4.3 Furnigation continued in transit	10
	3.5 Carriage of fumigated freight containers, barges and other	
	cargo transport units on a ship	15
	3.5.1 Loaded without ventilation after fumigation	15
	3.5.2 Fumigated freight containers, barges or other cargo	
	transport units ventilated before loading	16
	3.5.3 Furnigation after loading on board a ship	16
4	Control of rodent pests	
	4.1 General	17
	4.2 Fumigation and baiting	17
	4.3 Rodent baits (chronic poisons permitted for use by	
	whin's personnel)	17

•		
		Page
	5 Regulation for the use of pesticides	
	5.1 National and international controls on pesticides usage	18
	6 Safety precautions - General	
	6.1 Pesticide materials	18
	6.2 Space and surface spraying	19
	6.3 Fumigation	19
	6.4 Contact insecticides in the cargo space, admixture with	
	raw grain	20
	6.5 Exposure to pesticides resulting in illness	20
	Annex 1 - Pesticides suitable for shipboard use	21
177	Annex 2 - Threshold limit values (TLV) for vapours in air	25
	Annex 3 - Fumigation warning sign	26
	Annex 4 - IMDG Code Class 9 schedule for cargo transport unit	
	under fumigation	27
-	Annex 5 - Model checklist for in-transit fumigation with phosphine	28

- 3.4.3.19 During the final stages of discharge when it becomes necessary for personnel to enter the cargo spaces, such entry should only be permitted subsequent to verification that such cargo spaces are gas-free.
- 3.4.3.20 Upon completion of discharge and when the ship is found free of fumigants and certified as such, all warning signs should be removed. Any action in this respect should be recorded in the ship's log-book.
- 3.5 CARRIAGE OF FUMIGATED FREIGHT CONTAINERS, BARGES AND OTHER CARGO TRANSPORT UNITS ON A SHIP
- 3.5.1 LOADED WITHOUT VENTILATION AFTER FUMIGATION
- 3.5.1.1 If it is intended that freight containers, barges or cargo transport units containing cargo under furnigation should be taken on board ship without preliminary ventilation, their shipment must be considered as a Class 9 Hazard under the IMDG Code and as such the procedures should conform to the requirements as specified in the schedule for CARGO TRANSPORT UNIT UNDER FUMIGATION of the Code (see annex 4). The following special precautions, incorporating the IMDG requirements, are necessary:
 - A freight container, barge or cargo transport unit containing cargo under fumigation should not be allowed on board until sufficient time has elapsed to allow the attainment of a reasonably uniform gas concentration throughout the cargo. Because of variations due to types and amounts of fumigants and commodities and temperature levels, it is recommended that the period to elapse between fumigant application and loading should be determined locally for each country. Twenty-four hours is normally adequate for this purpose.
 - The master should be informed prior to loading of freight containers, barges and cargo transport units under fumigation. These should be identified with suitable warning signs* incorporating the identity of the fumigant, and the date and time of fumigation. Any freight container under fumigation must have the doors substantially secured before loading onto a ship. Plastic or lightweight metal seals are not sufficient for this purpose. The securing arrangement must be such as to allow only authorized entry to the freight container. If container doors are to be locked, the means of locking should be of such a construction that, in case of emergency, the doors could be opened without delay. Adequate instructions for disposal of any residual fumigant material should be provided.

A specimen of such warning sign is given in annex 3.

- .3 Shipping documents for freight containers, barges or cargo transport units concerned should show the date of fumigation and the type and amount of fumigant used.
- .4 Stowage 'on deck' should be at least 6m away from vent intakes, crew quarters and regularly occupied spaces.
- .5 Stowage 'under deck' should only be undertaken when unavoidable and then in a cargo space equipped with mechanical ventilation sufficient to prevent the built-up of fumigant concentrations above the TLV. The ventilation rate of the mechanical ventilation system should be at least two air changes per hour, based on the empty cargo space. The provisions of section 3.4.3.13 should apply.
- .6 Equipment suitable for detecting the fumigant gas or gases used should be carried on the ship, with instructions for its use.
- .7 Where the stowage requirements in 3.5.1.1.5 above cannot be met, cargo spaces carrying fumigated freight containers, barges or cargo transport units should be treated as if under fumigation and the provisions of 3.4.3.3 to 3.4.3.13 should apply.
- 3.5.1.2 Prior to the arrival of the ship, generally not less than 24 hours in advance, the master should inform the appropriate authorities of the country of destination and ports of call that sumigation in transit is being carried out. The information should include the type of sumigant used, the date of sumigation and cargo spaces carrying sumigated freight containers, barges or cargo transport units. Upon arrival at the port of discharge, the master should also provide information as required in 3.4.3.6.2 and 3.4.3.7.2.
- 3.5.2 FUMIGATED FREIGHT CONTAINERS, BARGES OR OTHER CARGO TRANSPORT UNITS VENTILATED BEFORE LOADING
- 3.5.2.1 Freight containers, barges or cargo transport units that have been ventilated after furnigation to ensure that no harmful concentration of gas remains should have the warning signs removed and, whether empty or loaded, may be taken on board a ship without the precautions in 3.5.1.1.1 to 3.5.1.1.7.

3.5.3 FUMIGATION AFTER LOADING ON BOARD A SHIP

3.5.3.1 No person should furnigate the contents of a freight container, barge or cargo transport unit once it has been loaded aboard a ship.